



Light Installation



Bag Contents:

- (1) clear light/batteries, (1) red light/batteries,
- (1) front bracket, (1) rear bracket, (2) 3/8" screws,
- (1) 1 1/4" screw, (1) 1/4" nut, (1) 1/4" jam nut

Remove clips and screws from back of lights. Insert batteries into lights. Snap posts on back of lights into bracket holes, and using a 3/8" screw, screw the brackets and lights together.

Front (clear light): Match bracket hole with hole in bucket left front rim. Insert the 1 1/4" screw through the holes. Thread nut onto screw and tighten.

Rear (red light): On trailer's left rear hinge, remove existing lock nut. Slide bracket onto screw and tighten replacement jam nut. Periodically check light alignment.