

# Rollbar Assembly Instructions

1. Loosen and remove the knob (1) connecting the handlebar/rollbar clamp and remove the outer handlebar/rollbar clamp (2).
2. Using a Phillips screwdriver and a 7/16" wrench, remove the nuts (3) from the mounting bolts.
3. From the inside of the trailer, pull the mounting bolts (5) until there is only 1/2" of thread sticking out from the inner handlebar/rollbar clamp.
4. Mount the rollbar into the inner handlebar/rollbar clamp (4) with the bolts inserted into the mounting holes on the rollbar. The rollbar should be mounted with the bent section of the rollbar pointed upwards and towards the front of the trailer (see diagram).
5. Push the mounting bolts thru the rollbar and thread the nuts onto the bolts.
6. Install the outer handlebar/rollbar clamp onto the rollbar, making sure to align the outer clamp with the nuts. Thread the knob thru the handlebar/rollbar clamps and tighten.
7. Using a Phillips screwdriver, tighten the mounting bolts.

